TiVo® Remote Control Reference

POWER turns the TV on or off.

VOL controls the volume on your TV.

TIVO takes you to the main menu.

MUTE turns the sound on or off.

CONTROLLER navigates using the UP, DOWN, LEFT or RIGHT areas.

BACK opens the main menu or returns to the previous screen.

LAST goes to the last viewed channel.

NETFLIX launches the Netflix app.

MICROPHONE for Voice Search.

INPUT selects the input for your TV.

GUIDE takes you to the on-screen Guide.

CH changes the channel up and down.

i shows more information about what you're watching.

OK, in the center of the Controller, accepts the current selection.

DVR lets you schedule new recordings and access existing recordings.

VOICE SEARCH finds your shows. On some remotes VOICE SEARCH looks like this:

APPS takes you to all your apps.

NUMBER BUTTONS enter numbers (e.g., channel numbers or Parental Controls PIN).

TiVo

© 2026 Xperi. All rights reserved. All other product and company names are trademarks or registered trademarks of their respective holders. Use of them does not imply any affiliation with or endorsement by them.